

CAUTION: ALWAYS INSTALL PRODUCT FROM LEFT TO RIGHT AND REMEMBER THAT POLYMER UNDERGOES EXPANSION/CONTRACTION DUE TO TEMPERATURE VARIATIONS. FOR A BETTER LOOK WE RECOMMAND TO INSTALL PRODUCT ON FLAT SURFACES (EX: PLYWOOD PANELS OR OSB PANELS). IF SECTIONS ARE INSTALLED ON A WALL WITH FURRINGS, FURRING STRIPS MUST BE INSTALLED OBLIQUELY AND SPACED BY 8”(20,32CM).

FRANÇAIS
AU VERSO

ESPAÑOL

PORTUGUÊS

РУССКИЙ

POLSKIE

1

1

2

3

3 1/2" (8,89cm)

8" MAX. (20,32cm)

2 1/8" (5,40cm)

1/4" (0,64cm)

Wall

Floor

1/4" (0,64cm)

2

When using TandoStone™ corners.

When used with J-channel or outside corner.

2 1/2" (6,35cm)

Outside corner or J-channel

1/4" (0,64cm)

3

For full length section.

Maximum 8" (20,32cm) between each nails.

x 8

4

Fasten each section at its center.

When installing a full section, nail in the center hole first.

When installing a cut section, nail in its center as shown.

For each nail.

1/16" (0,16cm)

Minimum 7/16" (1,11cm)

Minimum 1 1/2" (3,81cm)

5

Install sections and space equally. For installation when outside temperature is between 30°F(-1°C) and 100°F(38°C), press against previous section.

Between 30°F(-1°C) and 100°F(38°C)

Below 30°F(-1°C) Leave 1/16"(0,16cm)

Below 30°F(-1°C), position the section slightly right (1/16"(0,16cm)) previous section.

6

Alternate the joints between rows.

7

Center

1" (2,54cm)

If you need to attach the section in an area other than the installation hole, create a 1"(2,54 cm) long slot to allow nailing. Always nail in the middle of the slot.

8

CORNER INSTALLATION

1

2

3

4

First TandoStone™ corner.

Next TandoStone™ corners.

See TANDOCOMPOSITES.COM for the complete installation guide.

2025/08/27

DIV3013B-ENG